


PARTS AND HARDWARE

FOR A TYPICAL ASSEMBLY


ZINTRA STICKS
NARROW - 1" - (6)




NARROW - 2" - (4)



NARROW - 3" - (4)



NARROW - 4" - (2)




STANDARD ALUMINIUM TUBE WITH NOTCHES - (7)




YOU WILL NEED

FOR A TYPICAL ASSEMBLY


SPIRIT LEVEL




TYPE MEASURE



DRILL




DROP SAW WITH SUITABLE BLADE FOR ALUMINIUM CUTTING



SUITABLE SCREWS FOR DIFFERENT SURFACES - (14)

SCREWS ARE NOT INCLUDED - INSTALLER TO SUPPLY BASED ON FIXING SUBSTRATE



STEP 1


MEASURE THE HEIGHT [X] OF THE INSTALL AND CUT THE ALUMINIUM TO SUIT

NOTE: AFTER MEASURING AND MARKING WHERE TO CUT THE ALUMINIUM TUBE, COUNT THE NUMBER OF NOTCHES TO ENSURE IT WILL SUIT THE QUANTITY OF STICKS REQUIRED. FOR EXAMPLE, A WIDE STICK USES 4 NOTCHES, THEREFORE THE NOTCHES IN THE ALUMINIUM TUBE WILL NEED TO EQUAL A MULTIPLE OF 4.

USE A LASER LEVEL OR SPIRIT LEVEL TO MARK ALUMINIUM POSITION ON THE WALL.

MAX DISTANCE FROM TUBE CENTRES IS 450mm [17.71"]

MAX DISTANCE BETWEEN END OF STICK AND FIRST TUBE CENTRE IS 150mm [5.9"]



STEP 2


DRILL HOLES IN ALUMINIUM TUBES IN LOCATIONS TO SUIT SUPPORT IN WALL (STUD LOCATION ETC)

SCREW ALUMINIUM TUBES TO WALL

DRYWALL SURFACE: USE DRYWALL ANCHOR AND SUITABLE SCREW

TIMBER SURFACE: USE SELF TAPPING TIMBER SCREW



MASONRY SURFACE: USE MASONRY ANCHOR AND SUITABLE SCREW



STEP 3

FOLD ZINTRA STICKS - 2", 3", 4"

NOTE: ZINTRA STICK 1" - COMES FOLDED AND GLUED.




ZINTRA STICKS



CURVED - NARROW & WIDE

STEP 4

INSERT ZINTRA STICKS INTO TUBE NOTCHES
AS SHOWN



FOR BEST RESULTS USE CORRECT QUADRATIC
STICKS INSTALL SEQUENCE.
AS SHOWN



FINISHED INSTALL

NOTE: CAN ADD STICKS TRIM TO EDGES (SIDES OR BOTTOM)
FOR ALTERNATE FINISH

